



GATOR WRAP

INSTALLATION INSTRUCTIONS



1. Expose the area that is to be sealed. Clean the entire area around the joint with a wire brush and whisk broom. Remove any sharp protruding edges around the joint with an abrasive tool. When finished cleaning, the entire area must be dry and free of any dirt.



2. Remove the first foot of paper backing from the mastic. Center and place the Gator Wrap® around the joint. Continue to remove paper backing as you apply the Gator Wrap to the entire structure.



3. Seal the overlapping area with a 6" overlap. Be sure not to stretch material at the overlap area.



4. Cut excess material using a utility knife. Using a rubber mallet or hand held roller, firmly flatten the Gator Wrap® 360 degrees around joint.



Sealing Systems, Inc.

9350 County Road 19 ♦ Loretto, MN 55357 ♦ 763-478-2057 ♦ 800-478-2054 ♦ Fax 763-478-8868 ♦ www.infi-shield.com