



# SNAKEBITE™

## LOCKING CONNECTOR

### INSTALLATION INSTRUCTIONS

**PART# LSC1030C-\* /  
LSC1230C-\* /  
LSC1430C-\***



**ONE-TIME USE ONLY. MAKE SURE WIRES ARE INSERTED COMPLETELY BEFORE TWISTING TO LOCK.**

Do not use with stranded wire.

1. Strip wires 9/16"
2. Loosen set screws on connector
3. Align conductors
4. Place stripped wires into holes; use center hole for service line
5. Tighten set screws with Allen wrench; do not over torque
6. Firmly place connector in gel-filled cap and snap shut so all exposed wires and connector are covered

Do not reuse.

