

TWIST-ON CONNECTOR

INSTALLATION INSTRUCTIONS

PART# SCB-01 / SCB-01-LG





- 1. Strip wires 5/8" for SCB-01 or 3/4" for SCB-01-LG
- 2. Align conductors
- 3. Pre-twisting unnecessary; Place stripped wires together with ends of insulation even
- 4. Push wires firmly into connector
- 5. Twist connector onto wires pushing firmly until tight; do not overtighten Do not reuse.

Do not pull on wires after connection is made.



