



# COBRA™ HYDRANT FLANGE

## ACCESS POINT

### INSTALLATION INSTRUCTIONS

**PART# HYDFL**

1. Using existing hydrant hardware, mount Cobra Hydrant Flange to the hydrant base (clear of nozzle caps). \*\*\*\* Only use the washer when existing hydrant bolt is 1/2".
2. Remove gray PVC adapter from Cobra.
3. Set Cobra on top of hydrant flange.
4. Firmly screw PVC adapter into Cobra from under hydrant flange.

