



MAMBA ROUND LOCATE MARKER POST

INSTALLATION INSTRUCTIONS

PART# MAMBA-RND-L-*

1. Dig hole 18" deep by 6" wide (Fig 1).
2. Remove sleeve from the marker post (Fig 2).
3. Run tracer wire and ground wire up through the marker post, from bottom to top, so that wires come up in front of access point.
4. Slightly loosen the colored nuts on the tracer wire terminals on the access point.
5. Strip 3/4" of jacket from wire ends.
6. With a needle nose pliers, bend a pigtail on the tracer wire ends (ground wire can remain straight).
7. Hook pigtailed tracer wire ends (up to 5) around the appropriate screws (nuts color coded for identification purposes) between the nut and the washer. Tighten the nuts securely.
8. Slightly back out screw from ground block. Insert stripped ground wire and tighten screw to secure to exposed wire.
9. Rotate switch to "closed" position to ground up to 5 tracer wires. Rotate switch to "open" position to disconnect ground.
10. Place the top back onto the marker post.
11. Place post into ground (Fig 3).
12. Backfill dirt and tamp (Fig 4).

